



2062	MEDIDOR DE PARAFUSO GRANDES FRAGMENTOS <i>Large Fragments Screw Gauge</i>
2063	FRESA MACHO Ø 4,5 mm <i>Tap Reamer</i>
2064	FRESA MACHO Ø 6,5 mm <i>Tap Reamer</i>
2072	BROCAÇÃO INOX Ø 3,2 X 150 mm <i>Stainless Steel Drill</i>
2073	BROCAÇÃO INOX Ø 4,5 X 150 mm <i>Stainless Steel Drill</i>
2074	GUIA DE BROCA Ø 3,2 mm <i>Drill Guide For Plates</i>
2075	CHAVE SEXTAVADA 3,5 <i>Hexagonal Screwdriver</i>
2201	GUIA ÂNGULO 95° <i>Angled Guide</i>

2206	FRESA MACHO <i>Tap Reamer</i>
2208/01	FRESA COMBINADA 95° <i>Reamer</i>
2208/02	FRESA COMBINADA 35° <i>Reamer</i>
2209	IMPACTOR DE PLACA <i>Plate Impactor</i>
2210	GUIA ANGULADO 150° <i>Angled Guide</i>
2211	GUIA ANGULADO 135° <i>Angled Guide</i>
2212	CABO T <i>"T" Handle</i>
2249/02	AFASTADOR HOHMANN 35X255 <i>Hohmann Retractor</i>

3332	MEDIDOR <i>Gauge</i>
3333	GUIA DO MACHO <i>Tap Guide</i>
3334	GUIA DA PLACA <i>Plate Guide</i>
3335	PINO GUIA DA PLACA <i>Pin Plate Guide</i>
3336	GUIA DA CHAVE <i>Guide for "T" Wrench</i>
3337	CHAVE EM "T" <i>"T" Handle</i>
3338	GUIA DE PINO <i>Pin Fixator</i>
4692	GUIA FIO <i>Wire Guide</i>