



1792 GUIA DA FRESA ACETABULAR
Acetabular Reamer Guide

2004 IMPACTOR
Impactor

2006/01 CHAVE EM "T"
"T" Wrench

2010 IMPACTOR DE MULLER
Muller Impactor

2015 CABO DA RASPA
Reamer Handle

2016 GUIA ACETABULAR
Acetabular Guide

2017 GUIA DE BROCA
Drill Guide

GUIA MEDIDOR ACETABULAR
Guide Gauge Acetabular

REF.	Ø mm
1779/01	44
/02	46
/03	48
/04	50
/05	52
/06	54
/07	56
/08	58
/09	60
/10	62

2018 BROCA FLEXÍVEL Ø 3,2 mm
Flexible Drill

2021 CHAVE CONJUNTA UNIVERSAL
Universal Joint Driver

2052/03 PINO DE EXTRAÇÃO
Extraction Pin

2085 IMPACTOR DE INSERTO 22 mm
Insert Impactor

2086 IMPACTOR DE INSERTO 28 mm
Insert Impactor

2093 PINÇA PORTA PARAFUSO
Screw Forceps

FRESA RASPA SPOTORNO 7,0 mm
Broach Spotorno

REF.	TAMANHO / Size
1659/01	07
/02	08
/03	09
/04	10
/05	11
/06	12
/07	13
/08	15
/09	16

MEDIDOR DE CABEÇA Ø 28mm
Head Gauge

REF.	TAMANHO / Size
2858/01	C
/02	M
/03	L

MEDIDOR DE CABEÇA Ø 22MM
Head Gauge

REF.	TAMANHO / Size
2858/10	M
/11	L

MEDIDOR DE COLO
Colon Gauge

REF.	TAMANHO Size
7047/01	7 - 8 - 9
/02	10 - 11,25 - 12,5
/03	13,75
/04	15
/05	16,25

FRESA ACETABULAR
Acetabular Reamer

REF.	Ømm
2005/16	44
/17	46
/18	48
/19	50
/20	52
/21	54
/22	56
/23	58
/24	60
/25	62

FRESA FEMORAL LONGA CÔNICA
Conical Femoral Reamer

REF.	Ømm
2830/01	12

2727 GUIA DO MEDIDOR
Trial Measurer

2679 MEDIDOR DE PROFUNDIDADE FLEXÍVEL
Flexible Depth Gauge